ZANUSSI

Instructions for the use and care of your Z 80 Dishwasher

It is most important that this instruction book should be retained with the appliance for future reference. Should the appliance be sold or transferred to another owner, or should you move house and leave the appliance, always ensure that the book is supplied with the appliance in order that the new owner can be acquainted with the functioning of the appliance and the relevant warnings.

Dishwasher Warnings

THESE WARNINGS ARE PROVIDED IN THE INTEREST OF SAFETY. YOU MUST READ THEM CAREFULLY BEFORE INSTALLING OR USING THE APPLIANCE.

- Unplug the appliance and turn off the water after use.
- Any plumbing work to install this appliance should be carried out by a qualified plumber.
- Any electrical work required to install this appliance should be carried out by a qualified electrician.
- This appliance is designed to be operated by adults. Children should not be allowed to tamper with the controls or play with the products.
- This product should be serviced by an authorised Zanussi Network Service Centre, and only genuine Zanussi spare parts should be used.
- It is dangerous to alter the specifications or modify the product in any way.
- Care must be taken to ensure that the appliance does not stand on the electrical supply cable.
- Zanussi dishwashers are designed to be used for washing normal household utensils. Items that are contaminated by petrol, paint, steel or iron debris, corrosive, acidic or alkaline chemicals are not to be washed in a dishwasher.
- When finished loading or unloading close the door, as an open door can be a hazard.
- If your house is fitted with a water softening unit, it is not necessary to add salt to the water softening unit in the dishwasher.
- Do not put in your dishwasher: Cutlery with wooden or horn handles or glued parts, bronze cutlery, saucepans with wooden handles unless they are sold as dishwasher proof, aluminium ware, crystal ware, leaded glass, plastic articles unless sold as dishwasher proof, antique china or fine decorated china unless sold as dishwasher proof. Always check with the manufacturer of the item if in any doubt.
- A chemical reaction can occur between silver cutlery and stainless steel cutlery. As a precaution do not wash together.
- Under no circumstances should you open the door whilst the appliance is in operation. Always turn off the appliance before opening the door.
- Built-in dishwashers only: The appliance must be secured to the underside of the worktop using the brackets provided. Failure to do this could result in an unstable appliance which may cause damage or injury.
- Under no circumstances should you attempt to repair the appliance yourself. Repairs carried out by inexperienced persons may cause injury or more serious malfunctioning. Refer to your local Zanussi Network Service Centre. Always insist on genuine Zanussi spare parts.

Contents

Installation

Positioning	Page	3
Levelling	Page	3
Water Connection	Page	4
Electrical Connection	Page	5

Operation

Control Panel Description	Page	6
Loading the Crockery	Page	7
Loading the Rinse Aid	Page	9
Loading the Detergent	Page	10
Water Softener	Page	11
Starting the Machine	Page	14
Stopping the Machine	Page	14
Washing Programmes	Page	12/13

Care and cleaning

Cleaning the Filter	Page	14
Cabinet Cleaning	Page	16

Useful Hints Page 16

Something not working Page 17

Covering door & lower panel Page 18

Technical data

Width	23.6"
Overall Depth	22.4"
Overall Depth with open Door	47.2"
Height	33.4"
Capacity (in standard IEC place settings)	12
Supply Voltage	220/240 V - 50 Hz
Motor Rating during Washing	250 W
Heating Element Power	2800 W
Max. Power Absorbed	3050 W
Water Supply Pressure:	
minimum	7 p.s.i. - 49 kN/m^2
maximum	110 p.s.i. - 758 kN/m^2

Installation

Positioning

After removing the outer carton, set up the machine in the selected spot, preferably very close to water loading and draining facilities. Furthermore, the machine can be installed with the sides and back in touch with the adjacent furniture or with the wall.
The dishwasher features fill and drain hoses which can be turned either to the right or to the left (fig. 1) to suit the installation. The worktop can be adjusted either forwards or backwards up to 25 mm (1 in) to make it possible to align the machine properly with the kitchen furniture. To do this, simply remove the securing screws from the front (fig. 2); adjust the worktop as required, then replace the previously removed screws.
The machine can also be installed under the kitchen counter or under the sink. To do this, remove the worktop from the machine by unscrewing the two front securing screws and then release it from its rear catch. The dimensions of the special recess required to house the machine are given in fig. 3.

Levelling

The machine should be accurately levelled by adjusting the front levelling feet so that it be perfectly levelled (max. allowed error: ±2°). An accurate levelling is a must to ensure a correct operation of the machine.



fig. 1



fig. 2



fig. 3

Connection to the water supply

The machine may be supplied with either cold or hot water. **In the latter case, make sure that the temperature of the hot water never exceeds 60 °C (140 °F).**
The inlet hose should be connected to a 3/4" gas thread spout (fig. 4-5) or to a quick-coupling tap (Press-Block) after inserting the special strainer «A» supplied with the machine.
Make sure that the water supply pressure is within the limits indicated under the technical data (page 2).



fig. 4

Water outlet connection

The drain pipe from this machine must connect into the main drain from the premises, but not into the rainwater drain. Information as to the type of drain servicing your premises can be obtained from a builder or the Local Authority.
The curved end of the outlet hose should be firmly hooked over the edge of a sink (fig. 6), by using the curved end delivered with the appliance (fig. 7), or connected to a suitable drain pipe in the wall or under the sink; however, such a drain pipe should have a built-in air break in order to avoid water syphoning from the machine during draining. The top of the drain hose should not be lower than 30 cms (12 ins) or higher than 90 cms (36 ins) from floor level.
The water should be able to drain freely and the end of the outlet hose must not be under water. It is, therefore, advisable that the drain pipe, if used, has an internal diameter of at least 4 cms (1.5 ins). Also, ensure that the drain hose is not chocked or placed in such a way as to obstruct the normal water flow.
If the drain hose is to be hooked over the sink, ensure that the sink is empty and that the sink plug is not blocking the plug hole. If an extension is required, its inner diameter must be the same as that of the original hose of the washer and its length must not exceed 2 metres (6 ft.).



fig. 5



fig. 6

Electrical connection

WARNING:
THIS APPLIANCE
MUST BE EARTHED

The manufacturer declines to accept any liability should this safety measure not be observed.

IMPORTANT

The wires in this mains lead are coloured in accordance with the following code:

GREEN AND YELLOW - EARTH
BLUE - NEUTRAL
BROWN - LIVE

If you fit your own plug, the colours of the wires in the mains lead of your appliance may not correspond with the markings identifying the terminals in your plug, this is what you have to do:
Connect the green and yellow (earth) wire to the terminal in the plug which is marked with the letter «E» or the earth symbol ⏚ or coloured green, or green and yellow.
Connect the blue (neutral) wire to the terminal in the plug which is marked with the letter «N» or coloured black.
Connect the brown (live) wire to the terminal which is marked with the letter «L» or coloured red.
If the plug is not suitable it must be cut off and the appropriate plug fitted.
The cut off plug should be disposed of to prevent the hazard of electric shocks in case it should be plugged into a 13 Amp socket in another part of your home.
The plug moulded on to the cord incorporates a fuse. For replacement, use a 13 Amp Bs 1362 fuse. Only ASTA approved fuses should be used.
The fuse cover/carrier must be replaced in the event of changing fuse.
The ring fuse cover/carrier colour is the one shown by the coloured insert at the base of the plug.
The plug must not be used if the fuse cover/carrier is lost. A replacement cover/carrier must be obtained from Zanussi Service Agents whose addresses are listed on the attached «Zanussi Service Agents Nationwide».

This appliance complies with E.E.C. directive n. 76/889 of 4.11.76 relative to radio interference suppression.



fig. 7

Operation

Control panel

1 START and STOP Switch
2 Water Temperature Pushbutton
3 Economy drying button
4 «Machine-live» Indicator
5 Door handle
6 Salt Refilling Indicator
7 Programme Selector
8 Wash Cycle Phase Indicator



Programme Selector

This control permits selection of the required wash cycle.
Turn this knob clockwise until the index points exactly on the proper letter of the required wash cycle.
The indicator above the programme selector shows, at any given moment, what wash cycle phase the machine is carrying out at that particular moment.

Economy drying button

When depressed, it will cut out the final hot air drying phase. This is recommended for overnight washings. It will reduce power consumption.

Water Temperature Pushbutton

This pushbutton permits selection of the required water temperature.
When depressed, it will cause the water to heat up to 55 °C. By depressing it again and thus releasing this pushbutton, the wash water will heat up to 65 °C.

START & STOP Switch

By depressing this pushbutton the machine starts operating and, at the same time, the pilot lamp above this pushbutton will light up.
When depressing it again, the machine stops and the pilot lamp goes out.

Attention

Once this pushbutton is depressed, it is no longer possible to modify the setting of the other pushbuttons insofar as a mechanical safety locking device is actuated by the START & STOP pushbutton.
Therefore, when going through the various steps to select the programme, the START & STOP pushbutton should be absolutely the last one to be depressed.

Door Handle

Grip it firmly, pull it outwards. To close the door, simply push it back till it engages.

Salt Refilling Indicator

It tells you when the time has come to refill the salt in the container (see page 14).

Loading the crockery

Prior to arranging the crockery in the baskets, do remove the bigger food scraps (such as tiny bones, fish-bones, meat or vegetable scraps, fruit peels, etc) to prevent the filter from clogging, which would cause poor washing results. Open the door and slide out the baskets to be able to load the crockery.

Using the bottom basket (fig. 8-9).

The lower basket is designed to take pots, lids, dishes, salad-bowls, cutlery etc. The cutlery should be placed into the special small removable basket. To obtain good washing results, it is recommended to intermix spoons with knives and forks so that they will not stick together.
We also suggest that you stack the cutlery into the special small basket with the handles facing downwards. However, if the handles of your cutlery are very thin it is advisable to stack the cutlery with the handles facing upwards, so as to prevent them from sticking out from the bottom of the small basket and thereby blocking the lower sprayarm.



fig. 8



fig. 9

Using the top basket (fig. 10-11).

The top basket is designed to take dishes (dessert plates, saucers, flat plates, soup plates, up to a 24 cms 9.5 ins) diameter) plus cups and glasses which should be arranged as shown in the respective pictures.

Top basket raising and lowering

If very big plates (over 27 cm (10.6 ins) and up to 31 cms (12.2 ins) diameter) are normally used, the top basket will have to be raised to the upper position. This will make it possible to properly arrange these extra large plates in the bottom basket. To raise the top basket, remove the basket itself after taking off the front runner stops (fig. 12), remove the slides (B - fig. 13) after taking off the rear runner stops and refit them on the higher position (A - fig. 13), then replace the rear runner stops, the top basket and, finally, the front runner stops.
With the top basket on this upper position there is of course less loading clearance in the basket itself (which will in fact only take dishes up to 19 cms 7.5 ins) and this will also prevent utilization of the basket's raised cup compartments.



fig. 10



fig. 11

Important

When loading the crockery **be absolutely sure not to accidentally obstruct the water inlet funnel** at the centre of the upper basket.
Only a correct loading of the dishwasher will ensure good washing results.
After loading the crockery, make sure that the spray arms turn freely.



fig. 12



fig. 13



fig. 14



fig. 15

Jet strength control

The water jet strength of the upper spray arm can be adjusted by turning the water inlet funnel (A - fig. 14), to obtain the best washing results without risking that particularly light crockery is upset by the jets:
+ jet strength increase
— jet strength decrease.

Loading the rinse aid

The rinse aid dispenser, which automatically dispenses the right amount of rinse aid at the proper time, is located inside the dishwasher door. This special liquid product is essential to ensure prompt drying of the crockery and to make it come out crystal-clear since it prevents formation of stains due to the salts contained in the water.

Filling:press catch A (fig. 15) to open the container lid. Pour the rinse aid into the funnel.
The container holds approx. 150 cu.cms of rinse aid, which will last for about 70 wash cycles.
The lavel can be checked through the level indicator B (fig. 16).

Quantity: The quantity of rinse aid dispensed automatically from the container can be adjusted, in each single case, to compensate for hard or soft water, more being required for hard water and less for soft.
The quantity can be adjusted by means of knob C.

Important

We would suggest that you initially leave the knob on the preset position; only after a few wash cycles, if need be, should you increase the quantity of dispensed rinse aid if the crockery remains dull or shows occasional round spots.



fig. 16

Loading the detergent

The washing powder should be poured into compartment «D» of the container (fig. 17). If the lid of the container happens to be closed, to open it simply push back catch «E» which keeps it clamped down.

Quantity of Detergent: the quantity to be loaded depends on the brand used, on the degree of soil and type of load. On the average, we recommend 4 teaspoonfuls 25 grams (0.88 oz) if you have to wash normally soiled crockery, and up to 5 teaspoonfuls 30 grams (1 oz), for heavily soiled crockery.
Also take into account the detergent manufacturer's recommendations.
After loading the detergent in the proper compartment, close the lid.
The detergent will be automatically dispensed at the proper time.



fig. 17

Important

Only use detergents specially made for dishwashers;

To obtain fine washing results you should only use top quality detergents;

An insufficient quantity of detergent will give poor washing results, whereas an excessive quantity will not improve the results but will only represent a waste.



fig.18

Water softener

Depending on the area, water contains more or less limestone and mineral salts which tend to deposit on the crockery forming whitish markings that eventually cause all surfaces to become dull. The dishwasher incorporates a water softener which purifies the water of all limestone for dishwashing. In this way the cleaning action is greatly enhanced, no incrustations form and during the rinsing phases the crockery is restored to its original brilliance. Operation of the water softener is completely automatic.

Salt filling

After unscrewing the cap, fill 1,5 kg (3,3 lbs) of coarse cooking salt using the funnel supplied with the machine into the container on the tub bottom (fig. 18).
Carefully replace the container screwcap, making sure that the threading and the gasket have no trace of salt.
After this, it will suffice to periodically top up the container with salt only.
To remind you of this operation, the machine incorporates a salt refill indicator (6 page 8) graduated from number 1 to 20.
Following each wash cycle carried out, the indicator inches forward by one number so that, when the highest (20) number is reached, it means that salt has to be refilled even if the supply is not completely depleted.

Important

When the appliance is put into operation for the first time, it is recommended that you carry out a complete wash cycle without loading any salt in the respective container.
All salt refilling and topping up operations **should be carried out immediately prior to starting any one of the complete wash cycles** (with the exception of the RINSE & HOLD programme) in order to prevent the possibility that any salt granules or salt water, which might flow out of the salt container during refilling of the same, remain for some time on the bottom of the wash tub without being properly diluted.
Use only coarse cooking salt or specific equivalent products for water softeners.

Adjusting the water softener

The water softener is preset for water having a maximum hardness of 40 °F (22° d). This setting is designed to suit most of the field requirements. At any rate, if the water hardness exceeds 40 °F (up to a maximum of 60 °F), the water softener may be adjusted accordingly. This operation should be carried out by qualified personnel who should proceed as follows:

Remove the worktop as described on page 4 and 5.

Drill (pierce a 1-2 mm vent hole on point A of the plastic tank as shown in fig. 19.

Replace the worktop

Under normal operating conditions, the supply of salt in the container will last



fig. 19

Washing programmes

Program	Type of load and degree of soil
1	Extremely soiled crockery, pots, pans and cutlery
2	Normally soiled crockery, pots, pans and cutlery, with a normal quantity of food scraps
3	Normally soiled crockery, pots, pans and cutlery, with a reduced quantity of food scraps
4	Lightly soiled crockery, pots, and cutlery
5	Normally soiled crockery, plates and saucers, glasses and cutlery
6	Light soiled dishes and glasses with delicate decorations
7	Partial load (to be completed later in the day)

Recommended program	Program knob setting	Required pushbutton	Cycle description
Energetic with prewash	A	⏻	Cold prewash / Extended main wash up to 65 °C / 2 cold rinses 1 hot rinse / hot air drying
Universal with prewash	C	⏻	Cold prewash / Main wash up to 65 °C 2 cold rinses / 1 hot rinse / hot air drying
Universal no prewash	D	⏻	Main wash up to 65 °C 2 cold rinses / 1 hot rinse / hot air drying
Economy with prewash	A	E ⏻	Cold prewash / Extended main wash up to 55 °C / 2 cold rinses 1 hot rinse / hot air drying
Economy no prewash	B	E ⏻	Extended main wash up to 55 °C / 2 cold rinses 1 hot rinse / hot air drying
Gentle no prewash	D	E ⏻	Main wash up to 55 °C 2 cold rinses / 1 hot rinse Hot air drying
Rinse & hold	F	⏻	Cold rinse to prevent food scraps from drying up and sticking to the dishes
Economy Drying		E	If you require this type of drying, depress the relevant button.

for about 20 wash cycles, whereas by making the above-mentioned inlet hole, the salt supply will only last for about half as many wash cycles.
Therefore, the salt will have to be refilled in the respective container every time the salt refill indicator shows number 10 and number 20 respectively.

Starting the machine

After connecting the machine to the water supply and to the electric power supply, close the door and then proceed as follows:

Turn the programme selector knob to the required setting.

Depress the pushbuttons as required, if any (2-3 page 8).

Depress the START pushbutton (1 - page 8).

At this point a pilot lamp will light up and the machine starts operating.

Stopping the machine

When the wash cycle is completed, the machine stops automatically but the pilot lamp remains alight and to turn it off the STOP pushbutton has to be depressed. If you require to stop the machine at any moment during the wash cycle, simply depress the aforementioned STOP pushbutton. To restart the machine, depress again the same pushbutton and the wash cycle will resume from where it was interrupted.
It is not advisable to open the door during operation. At any rate, the machine incorporates a safety device which stops operation when the door is opened.
We would also recommend, at the end of a wash cycle, that you turn off the water tap and unplug the machine from the wall socket.

Care and cleaning

Cleaning the filter assembly

The filter assembly consists of a large circular fine-mesh filter (A) and two small cone-shaped filters (B -C), fitting one within the other, both being housed in the large filter (fig. 20).
We recommend that you inspect the two small filters B and C after each wash cycle, removing any food scraps that you might detect.
These two concentric filters can be removed by slightly turning the outer filter B anticlockwise until it disengages from its seat (fig. 20).
to remove the inner filter C, squeeze together the two small plastic tongues (fig. 21) sticking out from the bottom of outer filter B.
The large fine-mesh filter (A) should be cleaned from time to time (roughly once every two months) on both sides with a suitable brush.
To remove this large filter (A), take off the bottom sprayarm, and unlock part D fig. 22.
Replace the assembly reversing the above procedure, making sure that the outer rim of the circular filter fits correctly in its housing on the tub bottom.
The dishwasher should not be operated without the filters being correctly installed.
Periodic cleaning of the filters is essential for a smooth and efficient operation of the machine.



fig. 20



fig. 21

fig. 22

Cleaning the sprayarm nozzles

The holes of the sprayarm nozzles should not be obstructed as this would greatly reduce the effectiveness of the washing cycle.
To remove the bottom sprayarm release it from its securing catches and pull it out. To clean the nozzles of the top sprayarm, slide out the top basket whereby the sprayarm will become perfectly accessible.
To remove it, disengage conveyor A from its coupling and unscrew ring nut B (fig. 23).



fig. 23

Cabinet cleaning

The outer cabinet and the control board in particular should be wiped periodically with a soft damp cloth and, if necessary, with a little neutral detergent.
To clean these parts, never use abrasive products which might scratch the surface.

Long idle periods

If the machine is not to be used some time, it is advisable to take the following precautions:

Disconnect the machine from the electrical network and from the water supply;

Fill up the rinse aid container;

Leave the door ajar to prevent bad smells from lingering in the machine;

Leave the inner part of the machine clean, even if there is some crockery left, by carrying out at least a rinse & hold programme (n. 7).

If you are moving

If you are moving and the dishwasher is transferred to a new location, make sure that the machine is not tilted too much during transport.

Useful hints

It stands to reason that a machine of this standing should be utilized and exploited rationally and to its full capacity to make the most of it.
Therefore, place the crockery in the machine immediately after the meals, conveniently arranging the various pieces in the respective compartments.
If only partial loads are placed in the machine, do carry out a rinse & hold programme until the load is completed later in the day.
We would also suggest that you take into account the capacity and the space availability of your dishwasher when buying new crockery, particularly pots and pans, all of which should be suitable to be washed in the dishwasher.

Pots: this machine will also wash pots. Needless to say, the washing results depend on how soiled the pots are.
If there are plenty of dried up food scraps or if there are burnt scraps, it is advisable to pre-rinse the pots by hand or to pre-soak them so as to loosen the scraps.

Cutlery: as a rule, you should not wash in the dishwasher cutlery having wooden or horn handles or glued parts which will not withstand hot water.

Silver Cutlery: this may be washed in the dishwasher with very good results, provided it does not come in touch with steel cutlery. The fact is that the oxidizing effect of the soapy water might cause unsightly spots due to the chemical interaction between the two metals. Therefore they should be arranged separately in the cutlery basket.

Aluminium Ware: Aluminium is not very suitable for dishwashing.

Decorated Chinaware: some decorations might fade when machine-washed, just as it sometimes happens when washing it by hand, and we would therefore suggest that you wash one single piece a number of times in the machine and then compare it with the other pieces to see if the decoration has faded. At any rate, use only programme number 6 for such delicate crockery.

Cristalware and Plastic Ware: if these are not certified to withstand machine washing, you had better wash them by hand to play it safe.

Something not working

If there is a malfunction, make the following checks before you call for service: it may save you trouble and expense.

The Machine will not start

check that:

the door is correctly closed;

the water tap is full open;

the plug is perfectly inserted in the wall socket;

the fuses of the wiring system are not blown.

The machine will not drain

check that:

the drain hose is not kinked (bent);

the filter is not clogged.

The crockery does not come out clean

check that:

the detergent used is suitable for dishwashers and the quantity dispendes is the right one;

the crockery is correctly arranged in the baskets;

the sprayarms turn freely and the nozzles are not obstructed;

the filter is clean.

There are limestone deposits on the crockery

check that:

there is enough salt in the container;

the rinse aid supply is not depleted;

the quality of rinse dispensed is not insufficient.

There are traces of tea, coffee or lipstick left on the crockery

check that:

the quantity of detergent loaded in the machine is not insufficient:

Instructions for covering the door and the lower panel

The door and the lower panel of the appliance are fitted with suitable frames which can easily be removed to make it possible to cover them with a sheet of laminated plastic (or stainless steel).
In this way the dishwasher can be matched to the design of the kitchen furniture.
The dimensions of the laminated covering sheet should have the following measurements:

Door Covering Sheet:

Width	590 mm
Height	461 mm
Max. Thickness	4 mm

Lower Panel Covering Sheet

Width	590 mm
Height	114 mm
Max. Thickness	4 mm

To apply the covering sheet, proceed as follows:

Remove the lower panel (fig. 24) by loosing, without removing them, the two securing screws, and then free it from its top catch;

Remove the frames from the door and the lower panel after unscrewing the respective securing screws (fig. 24);

Fit the covering sheet and screw down the frames;

Refit the lower panel by fastening it first on the top catch and then retighten the two lower screws.



fig. 24

ZANUSSI STANDARD GUARANTEE CONDITIONS

This guarantee is in addition to your statutory and other legal rights which will not be excluded or in any way diminished by the return of the guarantee card.

We, Zanussi Limited, undertake that if, within twelve months (24 months for TV sets) of the date of the purchase, this ZANUSSI appliance or any part thereof is proved to be defective by reason only of faulty workmanship or materials, we will, at our option, repair or replace the same FREE OF ANY CHARGE for labour, materials or carriage on condition that:

—The appliance has been correctly installed and used only on the electricity supply stated on the rating plate.

—The appliance has been used for normal domestic purposes only, and in accordance with the manufacturer's operating and maintenance instructions.

—The appliance has not been serviced, maintained, repaired, taken apart or tampered with by any person not authorised by us.

—The appliance is still in the possession of the original purchaser.

All service work under this guarantee must be undertaken by a Zanussi Network Service Centre (or the Zanussi Authorised TV Service Dealer).

Any appliance or defective part replaced shall become our property.

Exclusions

This guarantee does not cover:

—Damage or calls resulting from transportation, improper use or neglect, the replacement of any light bulbs or removable parts of glass or plastic.

—Costs incurred for calls to put right machines improperly installed or calls to machines outside the UK and the Republic of Ireland.

—Appliances found to be in use within a commercial environment, plus those which are the subject or rental agreements.

—Television receivers - routine adjustment, or poor reception resulting from a source outside of the receiver.

ZANUSSI 5 YEAR COVER CONDITIONS

For a once-only payment you can extend your Standard Guarantee to 5 years. All the conditions and exclusions of the Standard Guarantee apply.

Notes

1. Products supplied as "seconds", refurbished, damaged or shop-soiled are not eligible for Zanussi 5 year cover.
2. The issue of a cover does NOT by virtue of our having done so, nullify the exclusions.
3. The Engineer will need to check the details of your Cover card and may make a charge for his services if it is not presented to him at the time of his call.
4. The date of purchase, or the date of initial payment (deposit) of the appliance will be deemed the date of commencement of cover.
5. Covers issued are not refundable or transferable.

ZANUSSI

The appliance of science

R538